



## **M00001633 & M00002421**

### **Installation document Splicing tent, 2.0 x 2.0 x 1.9 m, Maunt**



#### **Description**

Foldable splicing tent measuring 2.0 x 2.0 x 1.9 m that is quick to set up and provides shelter during splicing and installation work on site. Available in yellow (M00001633) and orange (M00002421).

#### **Brand**

Maunt

#### **Contents**

|               |    |
|---------------|----|
| Splicing tent | 1x |
| Carry bag     | 1x |
| Tent peg      | 3x |
| Guy rope      | 3x |

#### **Important before you start**

Treat the tent with impregnation spray before first use to make it fully waterproof. Do not use the tent during thunderstorms or storms; the tent is not flame-retardant. Use is at your own risk.

# MAUNT®



1. Take the tent out of the carry bag and place it on the ground. Note the small bag with the tent pegs and guy ropes inside the carry bag.



2. Check that all zips are closed. Lay the tent flat on the ground as a folded bundle, as shown in the photo.



3. Pull apart the four metal knobs (see the photo in step 2). Then pull the black loop on the roof; the roof will now unfold.



4. Once the roof has formed, carefully lift the sides. Pull the loop on the outside of each side wall towards you until the frame straightens and the side wall is taut. Tip: placing your foot on the bottom corner makes this easier.

**MAUNT**



5. Check that the tent is fully unfolded, all corners are stable and all panels and connections are secure. Anchor the tent with the supplied tent pegs and guy ropes using the eyelet in the middle of the side walls. This also prevents the tent from collapsing in strong wind.



6. Treat the tent with impregnation spray before first use and regularly thereafter. This makes the tent waterproof, protects the fabric against moisture saturation and extends its service life. Follow the instructions on the spray packaging.